Breville

Breville is a registered trademark of Breville Pty. Ltd. ABN 98 000 092 928

Breville Customer Service Centre Australian Customers

Breville Customer Service Centre

PO Box 22

Botany NSW 2019

AUSTRALIA

Customer Service: 1300 139 798

Fax (02) 9384 9601

Email Customer Service: askus@breville.com.au

New Zealand Customers

Breville Customer Service Centre

Private Bag 94411

Greenmount

Auckland, New Zealand

Customer Service: 0800 273 845

Fax 0800 288 513

Email Customer Service: askus@breville.com.au

www.breville.com.au





© Copyright. Breville Pty. Ltd. 2008
BarAroma is a trademark of Breville Pty. Ltd.
Due to continual improvements in design or otherwise,
the product you purchase may differ slightly from the one
illustrated in this booklet.
Model: BCG450 Issue 1/08

Breville

BarAroma™

Coffee & Spice Grinder



Inspiration. Every day.™

Contents

	Page
Breville recommends safety first	4
Know your Breville BarAroma™ Coffee and Spice Grinder	6
Operating your Breville BarAroma™ Coffee and Spice Grinder	7
Handy hints	8
Care and cleaning	9



Breville recommends safety first

Breville recommends safety first continued

We at Breville are very safety conscious. We design and manufacture consumer products with the safety of you, our valued customer, foremost in mind. In addition we ask that you exercise a degree of care when using any electrical appliance and adhere to the following precautions:

IMPORTANT SAFEGUARDS FOR YOU BREVILLE BARAROMA™ COFFEE AND SPICE GRINDER

- Carefully read all instructions before operating and save for future reference.
- To protect against electric shock, do not immerse the grinder, plug or cord in water or any other liquid.
- Remove any promotional stickers or packaging materials before using the coffee grinder for the first time.
- Do not place the appliance near the edge of a bench or table during operation. Always use the appliance on a dry, level surface.
- Always switch the appliance off, switch the power off at the power outlet and then remove the plug when the appliance is not being used and before cleaning.
- The Coffee Grinder should not be switched on until the bean container and lid are locked into position in the Grinding Chamber.
- Do not leave the appliance unattended when in use.
- Do not move the grinder whilst in operation.
- Do not place this appliance on or near a hot gas or electric burner, or where it could touch a heated oven.

- Do not use on metal surfaces, for example, a sink drain board.
- Do not use on an inclined surface.
- Do not operate this appliance for longer than 2 minutes at a time as this could cause overheating. Allow to cool for at least 2 minutes after each use. Allow appliance to cool down for 10-15 minutes after long operation.
- Keep the appliance clean. Follow the cleaning instructions provided in this book.

IMPORTANT SAFEGUARDS FOR ALL ELECTRICAL APPLIANCES

- · Fully unwind the cord before use.
- Do not let the cord hang over the edge of a table or bench, touch hot surfaces or become knotted.
- This appliance is not intended for use by young children or infirm persons unless they have been adequately supervised by a responsible person to ensure that they can use the appliance safely.
- Young children should be supervised to ensure that they do not play with the appliance.
- It is recommended to inspect the appliance regularly. Do not use the appliance if power supply cord, plug, connector or appliance becomes damaged in anyway. Return the entire appliance to the nearest authorised Breville Service Centre for examination and/or repair.
- Any maintenance other than cleaning should be performed at an authorised Breville Service Centre.

- This appliance is for household use only. Do not use this appliance for other than its intended use. Do not use in moving vehicles or boats. Do not use outdoors.
- The installation of a residual current device (safety switch) is recommended to provide additional safety protection when using electrical appliances. It is advisable that a safety switch with a rated residual operating current not exceeding 30mA be installed in the electrical circuit supplying the appliance. See your electrician for professional advice.

Know your Breville BarAroma™ Coffee and Spice Grinder



Operating your Breville BarAroma™ Coffee and Spice Grinder

BEFORE THE FIRST USE

Before first use, remove all promotional labels and packing materials attached to your Breville BarAroma™ Coffee and Spice Grinder.

OPERATING INSTRUCTIONS

- 1. Remove the Bean Container, Bean Container Lid and Ground Coffee Container and wash in warm soapy water with a soft cloth. Rinse and dry thoroughly. Before each use, ensure Grinder Bowl and Ground Coffee Container are clean and empty.
- 2. Place Bean Container into Grinding Chamber with 'Align' arrow symbol on the Bean Container aligning with the 'Align' arrow symbol on top left-hand side of the Grinder Base. Turn the Bean Container clockwise to lock into position.
- 3. Measure the desired quantity of whole coffee beans or spices directly into the Bean Container and cover with lid.
- 4. Plug the Grinder into a 230/240v power outlet and switch power outlet on.
- 5. Rotate the Bean Container to select the desired fineness of grind by aligning one of the following selections to the white marker on the front panel of the Grinding Base; COARSE - Percolator MEDIUM - Plunger

FINE - Filter

EXTRA FINE - Espresso

SUPER FINE - Turkish

6. Rotate the Timer Selector Dial (marked as number of cups) to select the desired grinding time.

- 7. Press the 'START' button on the front of the Grinder Base to begin grinding. The Coffee Grinder will begin grinding the coffee/spices directly into the Ground Coffee Container and will stop automatically when grinding is complete. To stop grinding cycle at any time, push the 'START' button again. If 'START' button is pressed again, grinder will start from beginning of timed cycle.
- 8. When finished, switch off at the power outlet and unplug grinder.
- 9. Clean Grinding Chamber with a soft dry cloth and rewind the power cord into the cord storage area under the Grinder base.
- 10. Remove the Bean Container, Bean Container Lid and Ground Coffee Container and wash in warm soapy water with a soft cloth. Rinse and dry thoroughly. Replace into position in the Coffee Grinder.

Handy hints

- For best flavour, store coffee beans in an airtight container.
- · Grind coffee beans immediately before brewing.
- Grinding times will vary depending on amount and grind fineness.
- To ensure optimal grinding performance, allow Coffee Grinder to cool for at least 2 minutes between uses.
- Coffee flavour and strength is a personal preference. Vary the type of coffee beans, amount of coffee and fineness of grind to find the flavour you prefer.
- To grind amounts not listed on controls, select the next closest amount.
- The Breville BarAroma[™] Coffee and Spice Grinder will not grind food that is sticky or extremely hard ie. chocolate, cheese, whole nutmeg, candied fruits, etc.
- The Breville BarAroma[™] Coffee and Spice Grinder will not make pastes of any fruits, seeds or herbs ie. curry pastes, nut batters.

THE GRIND (FOR ESPRESSO MACHINES)

- The coffee must be finely ground, but not too fine (the correct grind should look gritty, like salt or sand).
- If the grind is too fine, the water, when brewing, will not flow through the coffee even under pressure (this grind looks like powder and feels like flour when rubbed between fingers).
- If the grind is too coarse, the water, when brewing, will flow too fast through the coffee too fast, preventing a full flavoured extraction.

Care and Cleaning

Do not immerse Grinder, Power Cord or Plug in water or any other liquid. Do not fill the stainless steel Grinder Base or Grinding Chamber with water or any other liquid.

- 1. Unplug the appliance from the power outlet before cleaning.
- Remove Bean Container by turning counterclockwise to 'Align' symbols, then lift straight up.
- Remove the Ground Coffee Container by pulling out from the left-hand side of the Coffee Grinder.
- 4. The Removable Ground Coffee Container, Bean Container and Lid should be washed in warm soapy water, rinse and dried thoroughly.
- 5. Wipe base with a damp cloth. Wipe exterior of unit with slightly damp cloth. Polish with a soft, dry cloth. Do not use abrasives.

8

Notes	Notes